

Designed and Manufactured by:

www.classicautoleds.com

541.619.8335

Albany, Oregon

8. Pull the wiring back through the rubber boot until the new assembly is mounted on top of the boot.
9. Reinstall the lens. We suggest that you apply some silicon sealer to the back of the rubber boot where the wires pass through. This will help keep moisture out of the inside of the boot.
10. Repeat this process for the other side.
11. Test the lights and you are done.

Parts List

Description		Qty
1	LED Circuit Boards	2
2	10/32 x 3/4" Long SS Screws	4
3	#10 SS Flat Washers	4
4	10/32 SS Nylon Lock Nuts	4
5	1/4" SS Spacer	4

